



SOLAR SHADE

IMPORTANT: Read through entire instruction sheet before installing Solar Shade.

TOOLS REQUIRED:

9/64" Drill bit Pop rivet gun

Locate center snap at desired position on roller. Mark location and drill a 9/64" diameter hole UNDERNEATH valance, and into roller tube, **Figure 1**. Insert pop rivet (supplied) through snap base and into drilled hole in tube. Secure rivet with rivet gun. Secure Solar Shade to this snap, and mark location of other snaps, drill corresponding holes and rivet them in place. Additional snap bases can be installed at an EQUAL distance along the tube, to allow relocation of Solar Shade, **Figure 2**.

